

| Tool Model | Part No | Part Code | Description                |
|------------|---------|-----------|----------------------------|
| HN90F      | 1       | HN12229   | CYLINDER CAP PROTECTOR     |
| HN90F      | 2       | HN10067   | SCREW 6 X35                |
| HN90F      | 3       | HN12558   | CYLINDER CAP               |
| HN90F      | 4       | HN12247   | PILOT FILTER               |
| HN90F      | 5       | HH14040   | O-RING ARP568-040          |
| HN90F      | 6       | HN12215   | PISTON STOP                |
| HN90F      | 7       | HN12239   | PISTON STOP GUIDE          |
| HN90F      | 8       | HN12353   | SWEEPER                    |
| HN90F      | 9       | HN12382   | PISTON STOP GUIDE PLATE    |
| HN90F      | 10      | HN12243   | CYLINDER STOP GUIDE PLATE  |
| HN90F      | 11      | HH14034   | O-RING ARP568-034          |
| HN90F      | 12      | HN12218   | HEAD VALVE GUIDE           |
| HN90F      | 13      | HN12217   | HEAD VALVE PISTON          |
| HN90F      | 14      | HH11136   | O-RING ARP568-132          |
| HN90F      | 15      | HH14902   | O-RING AS 568-134          |
| HN90F      | 16      | KK23650   | COMP SPRING 3650           |
| HN90F      | 17      | HN12220   | SPRING HOLDER              |
| HN90F      | 18      | HH11806   | O-RING P27                 |
| HN90F      | 19      | HN70375   | Main Piston                |
| HN90F      | 20      | HH19915   | O-RING 2.6X34.6            |
| HN90F      | 21      | HH19167   | O-RING A 2.6X34.8 (CN-57)  |
| HN90F      | 22      | HN12470   | CYLINDER                   |
| HN90F      | 23      | HH11156   | O-RING ARP568-137          |
| HN90F      | 24      | HH11101   | O-RING 1AP38               |
| HN90F      | 25      | HN12225   | EXHAUST FILTER B           |
| HN90F      | 26      | HN12224   | EXHAUST FILTER A           |
| HN90F      | 27      | HN12223   | EXHAUST COVER L            |
| HN90F      | 28      | HN12244   | EXHAUST COVER R            |
| HN90F      | 29      | HN81347   | FRAME ASSY                 |
| HN90F      | 30      | HN12248   | GRIP COVER                 |
| HN90F      | 31      | PJ11961   | NAME PLATE                 |
| HN90F      | 32      | HN12115   | NAME RUBBER                |
| HN90F      | 33      | HN12549   | BLIND PLAT                 |
| HN90F      | 34      | HN12123   | TRIGGER LOCK DIAL          |
| HN90F      | 35      | KK23507   | SPRING 3507                |
| HN90F      | 36      | CN35075   | TRIGGER LOCK LEVER         |
| HN90F      | 37      | FF21235   | SPRING PIN 3X30            |
| HN90F      | 38      | HN10820   | FEED NOZZLE                |
| HN90F      | 39      | HH19722   | O-RING A1.5X5              |
| HN90F      | 40      | HH12105   | O-RING 1A 1.5 X 12.8 N5521 |
| HN90F      | 41      | HN10016   | TRIGGER VALVE HOUSING      |
| HN90F      | 42      | HH11820   | O-RING P6                  |
| HN90F      | 43      | HH11208   | O-RING BP6                 |
| HN90F      | 44      | HN12406   | PILOT VALVE                |
| HN90F      | 45      | HH11132   | O-RING 1AP10A CN65072      |
| HN90F      | 46      | KK29104   | COMPRESION SPRING 9104     |
| HN90F      | 47      | HH19707   | O-RING A1.4X2.5            |
| HN90F      | 48      | HN12407   | TRIGGER VALVE STEM         |
| HN90F      | 49      | HH19214   | O-RING 1B 1.5X3            |
| HN90F      | 50      | HN12172   | TRIGGER VALVE CAP          |
| HN90F      | 51      | HS10143   | CONTACT LEVER A            |

| Tool Model | Part No | Part Code | Description                                |
|------------|---------|-----------|--|
| HN90F      | 52      | HS10144   | CONTACT LEVER B                            |
| HN90F      | 53      | HS10147   | TRIGGER                                    |
| HN90F      | 54      | FF22402   | SPRING PIN 3X16 (LIGHT LOAD)               |
| HN90F      | 55      | HS10146   | SWITCH LEVER B                             |
| HN90F      | 56      | HS10145   | SWITCH LEVER A                             |
| HN90F      | 57      | CN34500   | LEVER SPRING                               |
| HN90F      | 58      | HN10786   | ARM GUIDE PLATE                            |
| HN90F      | 59      | HN10785   | CONTACT BUMPER                             |
| HN90F      | 60      | KK23735   | COMPRESSION SPRING 3735                    |
| HN90F      | 61      | KK23736   | COMPRESSION SPRING 3736                    |
| HN90F      | 62      | HN10818   | CONTACT ARM A                              |
| HN90F      | 63      | HN10784   | ARM GUIDE                                  |
| HN90F      | 64      | KK23129   | COMPRESSION SPRING 3129                    |
| HN90F      | 65      | HN10026   | ADJUST DIAL                                |
| HN90F      | 66      | HN12238   | ADJUST SPACER                              |
| HN90F      | 67      | HN12465   | BUMPER                                     |
| HN90F      | 68      | HH14734   | O-RING AS568-031                           |
| HN90F      | 69      | HN12606   | Nose                                       |
| HN90F      | 70      | EE39602   | WASHER 7                                   |
| HN90F      | 71      | BB40224   | SCREW 7X25                                 |
| HN90F      | 72      | HN10797   | RATCHET                                    |
| HN90F      | 73      | CN33679   | DOOR LUTCH                                 |
| HN90F      | 74      | KK33375   | SPRING 3375                                |
| HN90F      | 75      | FF41599   | PIN 1599 (REPLACES FF41587)                |
| HN90F      | 76      | HN12380   | DOOR                                       |
| HN90F      | 77      | KK23912   | COMP. SPRING 3912                          |
| HN90F      | 78      | EE39609   | RUBBER WASHER 1.8X6X2                      |
| HN90F      | 79      | FF31520   | STRAIGHT PIN 1520                          |
| HN90F      | 80      | FF41817   | STEP PIN 1817                              |
| HN90F      | 81      | CN35336   | CHECK PAWL                                 |
| HN90F      | 82      | KK33337   | SPRING 3337                                |
| HN90F      | 83      | FF31294   | PIN 1294                                   |
| HN90F      | 84      | HN10842   | FEED PAWL                                  |
| HN90F      | 85      | KK23710   | COMP. SPRING 3710                          |
| HN90F      | 86      | KK23788   | COMP. SPRING 3788                          |
| HN90F      | 87      | FF42216   | STEP PIN 2216                              |
| HN90F      | 88      | HH11111   | O-RING 1AP 14 N5522(REPLACES TA15260)      |
| HN90F      | 89      | HN10463   | FEED PISTON                                |
| HN90F      | 90      | HH11107   | O-RING AP18                                |
| HN90F      | 91      | KK23926   | COMP. SPRING 3926                          |
| HN90F      | 92      | KK23927   | COMP. SPRING 3927                          |
| HN90F      | 93      | CN31570   | CN37528 : FEED PISTON STOP                 |
| HN90F      | 94      | HN10464   | COMP. SPRING                               |
| HN90F      | 95      | JJ22407   | C-RING 26                                  |
| HN90F      | 96      | BB40460   | BOLT 5 X 28                                |
| HN90F      | 97      | HN12361   | CONTACT BOLT                               |
| HN90F      | 98      | HH11903   | O-RING 1A 1.2 X 4 T29051(REPLACES TA15277) |
| HN90F      | 99      | KK23952   | COPM. SPRING 3952                          |
| HN90F      | 100     | HN70378   | CONTACT ARM B UNIT                         |
| HN90F      | 101     | JJ10404   | E-RING 3.2                                 |
| HN90F      | 102     | BB40427   | T-BOLT 4 X 8(REPLACES TA15544)             |

| Tool Model | Part No | Part Code | Description                    |
|------------|---------|-----------|--------------------------------|
| HN90F      | 103     | EE39172   | WASHER 5.1X12X1.2              |
| HN90F      | 104     | CN31083   | HOOK, DUST COVER               |
| HN90F      | 105     | HN12548   | MAGAZINE SPACER                |
| HN90F      | 106     | HN10808   | ARM COVER                      |
| HN90F      | 107     | CC00401   | ELASTIC STOP NUT M5            |
| HN90F      | 108     | TA17024   | FILTER A                       |
| HN90F      | 109     | HN12070   | END CAP SEAL                   |
| HN90F      | 110     | HN12410   | END CAP                        |
| HN90F      | 111     | BB40704   | BOLT 4X12                      |
| HN90F      | 112     | HN10316   | END PLUG CAP                   |
| HN90F      | 113     | HN70264   | AIR PLUG H-FPM                 |
| HN90F      | 114     | BB40492   | T-BOLT 5X42                    |
| HN90F      | 115     | EE31121   | WASHER 1-5 (BLACK)             |
| HN90F      | 116     | HN70292   | HOOK ASSY                      |
| HN90F      | 117     | HN81352   | MAGAZINE CAP (AFTER)           |
| HN90F      | 118     | HN12467   | NAME LABEL                     |
| HN90F      | 119     | CN38159   | NAIL SUPPORT                   |
| HN90F      | 120     | CN38165   | E-RETAINING RING 6             |
| HN90F      | 121     | CN38161   | PLANE WASHER 8                 |
| HN90F      | 122     | CN38164   | COMPRESSION SPRING 8164        |
| HN90F      | 123     | CN38163   | BASE DIAL                      |
| HN90F      | 124     | CN38160   | NAIL POST                      |
| HN90F      | 125     | KK33396   | TOSSION SPRING                 |
| HN90F      | 126     | FF31642   | STRAIGHT PIN 8168              |
| HN90F      | 127     | HN12464   | WARNING LABEL                  |
| HN90F      | 128     | HN12468   | NAILSUPPORT SWITCH LABEL       |
| HN90F      | 129     | HN81353   | MAGAZINE (AFTER)               |
| HN90F      | 130     | HN12098   | STRAIGHT PIN(MAGAZINE HINGE)   |
| HN90F      | 131     | HN10100   | CONTACT LVER                   |
| HN90F      | 132     | KK33300   | SPRING 3300                    |
| HN90F      | 133     | HS10118   | TRIGGER                        |
| HN90F      | 134     | HN10400   | ARM GUIDE PIN                  |
| HN90F      | 135     | HS10117   | CONTACT ARM A GUIDE            |
| HN90F      | 136     | HN10817   | CONTACT TIP                    |
| HN90F      | 137     | HN10357   | CONTACT BUMPER                 |
| HN90F      | 138     | HN10401   | CONTACT ARM A                  |
| HN90F      | 139     | KK23619   | COMP. SPRING 3619              |
| HN90F      | 140     | HN10353   | TRIGGER VALVE STEM             |
| HN90F      | 141     | HA11031   | TRIGGER VALVE CAP              |
| HN90F      | 142     | HN12471   | DUST COVER                     |
| HN90F      | 143     | HS10704   | SCREW 6X38                     |
| HN90F      | 144     | HN10856   | FRAME HANGER                   |
| HN90F      | 145     | HN70337   | NOSE ATTACHMENT ASSY FOR HN90F |
| HN90F      | 201     | HN81354   | O-RING KIT                     |
| HN90F      | 202     | HN81307   | TRIGGER VALVE ASSY             |
| HN90F      | 203     | HN81350   | ARM GUIDE KIT                  |
| HN90F      | 204     | HN81351   | MAGAZINE ASSY                  |
| HN90F      | 205     | HN81348   | SEQUENTIAL TRIP KIT            |
| HN90F      | 206     | HN81355   | BODY HANGER KIT                |